

<b><u>Risk Assessment – Work at heights</u></b>							
<b>A. Hazard</b>	<b>B. Potential Risk What Goes Wrong</b>	<b>C. Risk Score</b>	<b>D. Risk Controls</b>	<b>E. Control Type</b>		<b>F. Res Risk Score</b>	<b>G. Person Responsible</b>
<b>Falls from heights</b>	<b>Death or serious bodily injury</b>	<b>20E</b>	<b>SWMS</b>	<b>Admin</b>	<b>2</b>	<b>16</b>	<b>PCBU. S.</b>
			<b>Tool box talk</b>	<b>Admin</b>	<b>2</b>		<b>PCBU. S. W.</b>
			<b>Supervision</b>	<b>Admin</b>	<b>2</b>		<b>PCBU. S.</b>
			<b>Harness</b>	<b>PPE</b>	<b>1</b>		<b>PCBU. S. W.</b>
			<b>Work at heights training</b>	<b>Admin</b>	<b>2</b>		<b>PCBU. S. W.</b>
			<b>Edge protection</b>	<b>ISE</b>	<b>3</b>		<b>PCBU. S.</b>
			<b>Signage</b>	<b>ISE</b>	<b>3</b>		<b>PCBU. S.</b>
			<b>Engineered anchor points</b>	<b>ISE</b>	<b>3</b>		<b>ALARP</b>
<b>A. Hazard</b>	<b>B. Potential Risk What Goes Wrong</b>	<b>C. Risk Score</b>	<b>D. Risk Controls</b>	<b>E. Control Type</b>		<b>F. Res Risk Score</b>	<b>G. Person Responsible</b>
<b>Falling objects</b>	<b>Death or serious bodily injury</b>	<b>20E</b>	<b>SWMS</b>	<b>Admin</b>	<b>2</b>	<b>17</b>	<b>PCBU. S.</b>
			<b>Tool box talk</b>	<b>Admin</b>	<b>2</b>		<b>PCBU. S. W.</b>
			<b>Supervision</b>	<b>Admin</b>	<b>2</b>		<b>PCBU. S.</b>
			<b>Exclusion zones</b>	<b>ISE</b>	<b>3</b>		<b>PCBU. S.</b>
			<b>Signage</b>	<b>ISE</b>	<b>3</b>		<b>PCBU. S.</b>
			<b>Hard hats for workers below</b>	<b>PPE</b>	<b>1</b>		<b>PCBU. S. W.</b>
			<b>Training of workers</b>	<b>Admin</b>	<b>2</b>		<b>PCBU. S.</b>
			<b>Site induction</b>	<b>Admin</b>	<b>2</b>		<b>ALARP</b>

**ALARP = As low as Reasonably Practicable. You must monitor worker compliance with the SWMS.**